

Vinnic[®]


**iPad PRO 13" MAGNETIC
LEVITATION KEYBOARD**

VPMA-KBMS129TCG1-BK

user manual

■ English ■ Deutsch

PRODUCT DESCRIPTION




- 1** Hot keys
- 2** Keyboard
- 3** Trackpad

- 4** On/Off switch
- 5** Type-C Charging Port
- 6** Bluetooth connect button

PAIRING

- 1 Turn on the keyboard Power **(3)**.
- 2 Press the **(5)** Bluetooth connect button, the status light blinks blue.
- 3 On your iPad, make sure Bluetooth is on.
- 4 Select **"Vinnic Pro 13"** from the Devices menu.
- 5 When successful connection is made, the status light turns solid blue.



HOT KEYS

 esc	iPad Home screen		Trackpad On / Off
	Brightness -		Previous track
	Brightness +		Play / Pause
	Mission control		Next track
	Search		Volume -
	Siri / Voice text		Volume +
	Screen capture		Lock screen

HOT KEYS



Switch Language



+



Backlight brightness adjustment

Backlit keys 3 brightness levels

(Right)

CHARGING

- 1 When the keyboard's battery is low, the low-battery indicator will blink repeatedly, signaling the need to charge.
- 2 Attach the USB Type-C cable to the keyboard's charging port (4).
- 3 The charging indicator (red) will remain lit during charging and turn green when fully charged.



SLEEP MODE


The keyboard automatically switches to sleep mode following 15 minutes of inactivity, deactivating the indicator light. To wake it, hold down any key for 3 seconds, and the indicator light will reactivate.

TROUBLESHOOTING

- 1 Verify that the power is switched on.
- 2 Check that the keyboard is within the operational range.
- 3 Confirm the battery has sufficient charge.
- 4 Make sure the device's Bluetooth is activated.
- 5 Ensure the wireless keyboard is connected via Bluetooth.
- 6 Confirm the wireless keyboard has been paired successfully.

ATTENTION

- 1 Keep the keyboard turned off when not in use for long durations to save battery.
- 2 Recharge before the power indicator starts blinking, allowing at least 2 hours of charging to enhance battery efficiency.

PRODUKTBESCHREIBUNG

- 1** Hotkeys
- 2** Tastatur
- 3** Trackpad

- 4** Ein-/Ausshalter
- 5** Type-C Ladeanschluss
- 6** Bluetooth-Verbindungsknopf

PAIRING

- 1 Schalten Sie die Tastatur ein(3).
- 2 Drücken Sie den (5) Bluetooth-Verbindungsknopf, das Statuslicht blinkt blau.
- 3 Stellen Sie sicher, dass Bluetooth auf Ihrem iPad eingeschaltet ist.
- 4 Wählen Sie „**Vinnic Pro 13**“ im Menü Geräte aus.
- 5 Wenn die Verbindung erfolgreich hergestellt wurde, leuchtet das Statuslicht konstant blau.



TASTENKOMBINATIONEN

 esc	iPad-Startbildschirm		Trackpad Ein / Aus
	Helligkeit -		Vorheriger Titel
	Helligkeit +		Wiedergabe / Pause
	Missionskontrolle		Nächster Titel
	Suche		Lautstärke -
	Siri / Sprachtext		Lautstärke +
	Bildschirmaufnahme		Bildschirm sperren

FUNKTIONSTASTEN



Sprache wechseln



+



Anpassung der Hintergrundbeleuchtung
Hintergrundbeleuchtungstasten mit 3
Helligkeitsstufen

(Rechts)

LADEN

- 1 Wenn der Akku der Tastatur schwach ist, blinkt die Niedrig-Akku-Anzeige wiederholt und signalisiert, dass eine Aufladung erforderlich ist.
- 2 Schließen Sie das USB-Type-C-Kabel an den Ladeanschluss der Tastatur **(4)** an.
- 3 Die Ladeanzeige (rot) bleibt während des Ladevorgangs eingeschaltet und wird grün, wenn sie vollständig aufgeladen ist.



SCHLAFMODUS

Die Tastatur wechselt nach 15 Minuten Inaktivität automatisch in den Schlafmodus und deaktiviert das Kontrolllicht. Um sie zu wecken, drücken Sie eine beliebige Taste 3 Sekunden lang, und das Kontrolllicht wird reaktiviert.

FEHLERSUCHE

- 1** Überprüfen Sie, ob der Strom eingeschaltet ist.
- 2** Stellen Sie sicher, dass die Tastatur im Betriebsbereich ist.
- 3** Bestätigen Sie, dass der Akku über ausreichend Ladung verfügt.
- 4** Stellen Sie sicher, dass Bluetooth des Geräts aktiviert ist.
- 5** Sicherstellen, dass die drahtlose Tastatur über Bluetooth verbunden ist.
- 6** Bestätigen Sie, dass die drahtlose Tastatur erfolgreich gekoppelt wurde.

ACHTUNG

- 1** Halten Sie die Tastatur ausgeschaltet, wenn sie über längere Zeit nicht verwendet wird, um den Akku zu schonen.
- 2** Laden Sie auf, bevor die Stromanzeige zu blinken beginnt, und erlauben Sie mindestens 2 Stunden Ladezeit, um die Akkueffizienz zu verbessern.

VINNICPOWER.COM

Manufacturer: Vinnic Power Company Limited.
Address: Unit B, 2/F., Wah Shun Industrial Building,
No.4 Cho Yuen Street, Yau Tong Bay, Kowloon, Hong Kong.
EC REP: OBELIS S.A, Bd. Général Wahis 53, 1030, Brussels.

